


# Layout diagram leXsolar-Wind Ready-to-go 2.0

Item-No.1405

Bestückungsplan leXsolar-Wind Ready-to-go 2.0

Art.-Nr.1405



- |  |  |
|--|--|
| <p><b>1</b> 1400-19 leXsolar Wind machine<br/>1400-19 leXsolar Windzeuger</p> <p><b>2</b> 1100-19 leXsolar-Base unit<br/>1100-19 leXsolar-Grundeinheit groß</p> <p><b>3</b> 1400-07 Capacitor module 220 mF, 2.5V<br/>1400-07 Kondensatormodul 220 mF, 2.5 V</p> <p><b>4</b> 1100-22 Resistor module<br/>1100-22 Widerstandsmodul</p> <p><b>5</b> 1100-26 Light bulb module<br/>1100-26 Glühlampenmodul</p> <p><b>6</b> L2-06-027 Anemometer<br/>L2-06-027 Windgeschwindigkeitsmesser</p> <p><b>7</b> 1400-16 Stator for anemometer<br/>1400-16 Windmesser-Ständer</p> | <p><b>8</b> L2-06-012/013 Test lead black/red 25 cm<br/>L2-06-012/013 Messleitung schw./rot 25 cm</p> <p><b>9</b> 2xL2-06-014/015 Test lead black/red 50 cm<br/>2xL2-06-014/015 Messleitung schw./rot 50 cm</p> <p><b>10</b> 1400-01 Savonius rotor module<br/>1400-01 Savoniusrotormodul</p> <p><b>11</b> 9100-05 PowerModul<br/>9100-05 PowerModul</p> <p><b>12</b> 2xL2-06-011 Digital multimeter<br/>2xL2-06-011 Digitalmultimeter</p> |
|--|--|

Version number  
Versionsnummer

L3-03-133\_04.11.2015






## Layout diagram leXsolar-Wind Ready-to-go 2.0

Item-No.1405

### Bestückungsplan leXsolar-Wind Ready-to-go 2.0

Art.-Nr.1405



- 13** 1400-08 LED-module 2mA, red  
1400-08 LED-Modul 2 mA, rot
- 14** 1100-25 Buzzer module  
1100-25 Hupenmodul
- 15** 1400-22 Wind turbine module with **18**  
1400-22 Windturbinenmodul mit **18**
- 16** 1100-23 Potentiometer module  
1100-23 Potentiometermodul
- 17** 1400-12 leXsolar-Wind rotor set  
(8 blades, 6 hubs, 2 caps)  
1400-12 leXsolar-Windrotoren  
(8 Flügel, 6 Naben, 2 Kappen)

- 18** Wind turbine with **15**  
Windturbine mit **15**
- 19** 1100-27 Motor module without gear  
1100-27 Motormodul ohne Getriebe
- 20** 1100-28 Color discs with mount Set 1  
1100-28 Farbscheiben Set 1